

## Installation Instructions


Read Carefully →

Thank you for purchasing from IllumiSeal!

These superior dock lights are easily installed by the homeowner, and are literally plug-and-play.


1. Ensure the light is unplugged before handling.

2. Snap the curved strap on the power cord into the base of the transparent light housing.



3. Screw the sacrificial anode into the bottom of aluminum frame. The sacrificial anode will erode over time to protect the underwater light from corrosion. The life span of the sacrificial anode will depend on the surrounding conditions, but the sacrificial anode should be checked after being in the water for approx. 30 days to see the rate of erosion to get a base line on how long it will last. A new anode is 2 inches long, and it should be replaced before it erodes to less than 1 inch long. Replacement anodes can be ordered at [www.illumiSea.com](http://www.illumiSea.com) or by calling 971-Aquatic.

4. To achieve desired depth of the light, adjust the anchor weight by loosening the screws on the anchor and sliding it closer or further from the light. To ease sliding you may lubricate the cord with water. Tighten the screws to lock the anchor weight on the cord.



5. Secure the power supply to a structure above the water. (screws are not provided)

6. Place both the light and anchor into the water at desired location.

7. Plug the electrical cord into a GFCI outlet.\*\*

Sit back and enjoy !

